
SINCE 1950

ALASKA



AR-2 使用手冊/附保證書

ⓘ 請詳細閱讀使用說明書後再使用閱讀後請妥善保存

初次設定

1. 下載 Ultron Utility App

Google Play 立即下載

App Store 下載

「Google」、「Android」和「Google Play」是 Google LLC 的商標。
App Store 是 Apple Inc. 的商標。

2. 開始連網

登入帳戶→建立「位置」→ 點選主頁下方「掃描」按鈕 → 掃描裝置上的 QRcode 並為裝置命名→ 完成裝置安裝。

請將裝置插上電源 →回到手機 App 畫面 → 完成 WiFi 配置 →「加入」→ 回主頁 → 裝置於「未啟用裝置」區域跳至下方「我的裝置」列表即連線成功 (亦可從裝置燈號或聲響辨識連線狀態)。

連線排解

裝置無法連線

若裝置停留在「未啟用裝置」區域，您可以點選該裝置，依照 App 指示，重新設定 Wi-Fi；回到首頁，當裝置出現於「我的裝置」列表即連線成功。

裝置離線

若裝置在 App 的「我的裝置」列表呈現反灰，請點擊該裝置，進入後再點擊「協助您重新連回網路」，並依 App 指示，將裝置重回預設值 *，再重新設定 Wi-Fi；回到首頁，當裝置出現於「我的裝置」列表即連線成功。

* 請參照該裝置說明手冊，將裝置重回預設值。


更換裝置 Wi-Fi 設定

1. 請參照該裝置說明手冊，將裝置重回預設值。
2. 待裝置離線（呈現反灰），點擊該裝置進入後，再點擊藍字「協助您重新連回網路」，重新設定 Wi-Fi。

刪除裝置

請在 App 主頁中的「我的裝置」選擇該裝置，進入後點擊頁面右上方的「⋮」，再點擊最下方「刪除」即完成裝置刪除。

App 介面



加入 Google Home應用程式

1. 下載 Ultron Utility App

從Google Play商店或App Store下載「Google Home」應用程式;並與Ultron Utility登入同帳户。

2. 連接 UltronSMART :

點選左上方「+」符號 → 點選「設定裝置」→ 點選「Google 的合作夥伴」或「與Google服務連結」→ 搜尋「UltronSMART」,選擇 Ultron Utility 同帳戶。(如下圖) → 所有裝置即出現在Google Home 應用程式的主頁中。



使用 Google 助理語音控制

以下裝置語音控制示範以「風扇」代稱。

1. 啟用 Google 助理 * ：

Android 用戶請直接長按 Home 鍵啟用 Google 助理；

iOS 用戶請至 App Store下載「Google 助理」應用程式。

* 需要網際網路連線。

2. 裝置控制使用示範：

開啟 Google 助理，登入與「Google Home」同帳戶；

說「Ok Google, 打開風扇。」所有風扇即打開。

若控制單一裝置，分別說

「Ok Google, 打開風扇一。」

「Ok Google, 打開風扇二。」


名稱為風扇一、風扇二的裝置即分別打開。

(需事前從 Google Home 應用程式設定自訂裝置名稱。)


支援 Ok Google

安裝方式

1 手機掃描Wi-Fi控制模組(AR-2)上QR code進行連線。




2 使用工具將蓋子卸下，並妥善保存。



安裝方式

3 掃描後將Wifi控制模組(AR-2)插入插槽，蓋回「蓋子」。



4 成功連上網路，即可使用APP和語音操作。




燈號顯示(連線)

連線燈號

1. 橘燈閃爍 - 等待設定

2. 橘綠燈閃爍 - 連接中

3. 綠燈恆亮 -連線成功




燈號顯示(重置)

重置燈號 (長壓約20秒)

1. 橘.綠燈快速閃爍 - 重置中


2. 橘燈恆亮(2秒) - 完成重置



※需安裝在機體上，方能重置

Wi-fi控制模組更新

1 進入控制頁面點擊「⋮」




2 再次點選韌體更新即可



Wi-fi控制模組解綁

1 進入控制頁面點擊「⋮」



2 再次點選最下方「刪除」



產品規格

型　　號	AR-2
產品淨重	15g
包裝尺寸	81x72x30mm
數　　量	1set

售後服務

1. 承蒙愛顧本公司產品。本保證卡享有自購買日起主要零件(風扇馬達)兩年、一般零件1年基本保固免費服務，但如有下列情形之一者，雖在服務期間內，亦得酌收成本費或服務費。
2. 未於本公司網站登入保證卡、或未出示保證卡、或無購買日期、或未蓋經銷者章、或未出示入宅時間證明。

非保修

1. 使用不慎或錯誤或未依本說明書要求定期維護而導致之損壞。
2. 自行拆卸、改裝或更換非原廠零件所發生的故障。
3. 經安裝後購買人自行搬移或運送所發生破損。
4. 因天災地變或不可抗拒之外力所導致損壞。

※服務後保證說明事項


1. 保固期間內之維修，產品仍以該原保固期間予以保固。
2. 保固期間外之維修，維修零件保固為期三個月。

總　公　司：台中市豐原區水源路490號　　電 話：04-25222186
台北營業所：台北市士林區前港街　98號　　電 話：02-28827905
桃竹營業所：桃園市楊梅區瑞坪路272號　　電 話：03-4812068
高雄營業所：高雄市左營區重偉街　71號　　電 話：07-3504566

02000179-A3

SINCE 1950


ALASKA




AR-2 WiFi控制模組(搭配AL-7偵測型控制器)
安裝使用手冊

連接線安裝

1 將連接線端子依圖示插入控制器的端子。




2 將連接線USB座依圖示插入WiFi控制模組。



WiFi控制模組安裝-安裝於單(雙)連box


1. 控制器安裝於單(雙)連box時，WiFi控制模組與連接線可存放於單(雙)連box內。




2. 因安裝環境不同，此安裝方式可能導致連線品質降低。

WiFi控制模組安裝-安裝於無開孔牆面


1. 以工具將控制器左或右欲出線方向的塑膠隔板夾除。



2. 控制器安裝於無開孔牆面時，WiFi控制模組與連接線由壁蓋的左或右一側導入，由壁蓋的缺口處出線。



ALASKA



AR-2 Operation Manual with Warranty Card

Please read this manual thoroughly before using and save it for future reference.

Set up your device

Wi-Fi Module is referred to as “device” in the following sections.

1. Download the “Ultron Utility” App from the App Store or the Google Play Store.

GET IT ON Google Play

Download on the App Store

2. Sign in with your Google Account > Create [Location Name] > Tap [Scanning Button] in the bottom of the Dashboard > Scan the QR code on the device.
3. Make sure the device is installed > Back to the App Dashboard, complete the Wifi setting by following the remaining steps on the App.
4. The device is connected to the network when the device icon has moved from [Unactivated Area] to [Devices]. The LED light of the device also visually illustrates its status; the device is connected when the light turns green steadily.

App Dashboard


Location Name

Unactived Area

Scenes

Scanning Button

Tap to scan the QR code on the device.



Change Wi-Fi Setting


Reset the device to default, then start the setup process over again.

Powered by ULTRON

Integrate Google Service

1. Download the “Google Home” App from the App Store or the Google Play Store > At the top right, tap your account > Verify that the Google account shown is the one linked to “Ultron Utility” App.

2. At the top left, tap [+] > [Set up device] > [Work with Google] > search and tap “UltronSMART” > Sign in to the app with the same Google account.



Google Play and the Google Play logo are trademarks of Google LLC.
App Store is trademarks of Apple Inc.

Voice user interface

We use “Fan” as an example in the following instructions. Please change the name of your devices depending on your current condition.

1. Download and open the “Google Assistant” App.

2. Sign in with your Google Account, the one linked to the “Ultron Utility” App.


- Control multiple devices at a time
  Say “Ok Google, turn on the fan.”
  All fans will be turned on.

- Control specific device(s)
  Say “Ok Google, turn on the fan 1.”
  and “Ok Google, turn on the fan 2.”
  The fan 1 and 2 will be turned on accordingly.
  (Need to name these two devices on the “Google Home” App ahead.)


works with Ok Google

Installation

1. Open the “Ultron Utility” App on your phone, scan the QR code on the AR-2 Wi-Fi Module.




2. Remove the lid on the ALASKA product and keep it.




Installation

3 Plug the AR-2 Wi-Fi Module in the USB port, and put the lid back.




4 Complete the Wifi setting by following the remaining steps on the App, and you will be able to control the ALASKA product via App or voice.



Light Signal (Setup Process)

Pulse (Orange Light):
Connecting Wi-Fi,
or Waiting for connection.

Solid (Green Light):
Connected to the Wi-Fi.




Light Signal (Reset)

Pulse (Orange and Green Light):
Reset default


Solid for 2 seconds (Orange Light):
Reset is complete.


*Verify the device is installed before you start the reset process.

*The Wi-fi module(AR-2) must be installed in the slot to reset.



Delete Device from App





Specification

Model	AR-2
Net weight	15g
Dimension	81x72x30mm
Quantity	1set

After service

1. Thank you for purchasing our product(s). This warranty card provides 2-years warranty for main parts (fan motor) and 1-year basic warranty for general parts from the date of purchase. However, if one of the following circumstances occurs, the cost or service fee maybe charged during the warranty period.
2. The warranty card has not been registered on the company's website, or the warranty card has not been presented, or there is no date of purchase, or the seal of the distributor has not been stamped, or the proof of time of entry has not been presented.

Non-warranty

1. Damage is caused by inadvertent or incorrect use or failure to perform regular maintenance as required by this manual.
2. The user disassembles the product, modifies the product or uses non-original parts.
3. Damage is caused by natural disasters or force majeure.


* Post-Service Warranty

1. During the warranty period, the product is still warranted during the original warrantyperiod.
2. If maintenance is conducted outside the warranty period, the repair parts are warranted for a period of three months.

Headquarters :
No.490, Shuiyuan Rd., Fengyuan Dist., Taichung City 420, Taiwan (R.O.C.)
TEL：+886-4-25222186

02000183-A2

ALASKA




AR-2 Wifi Module + AL-7 Intelligent Controller


Operation manual

Connection Cable Installation

1. Insert the connection cable terminal into the controller port.




2. Insert the WiFi module (AR-2) into the USB port on the connection cable.



WiFi Control Module Installation

Installation in a Single (Double) Gang Box

1. When installing the controller in a single or double gang box, the WiFi control module and connection cable may be placed inside the box.




2. This installation method may reduce connection quality, depending on environmental conditions.

WiFi Control Module Installation

Install on a solid wall surface without openings

1. Use a tool to remove the plastic knockout plate on the left or right cable outlet of the controller.



2. When installing the controller on a solid wall without openings, the WiFi module and connection cable should be routed through the left or right side of the wall plate and exit through the wall plate opening.

